UI Bulletin #204

Subject: Installing Tahoe PPV/SSV Emergency Lighting and Aftermarket Equipment - Liftgate Struts Warning

Models Years Affected:	All Model Years
Models Affected	TAHOE 9C1 PPV
Origination Date:	9/25/2024
Revision Date:	N/A

ADVISORY:

Condition/Concern:

Some Customers, Upfitters, or Dealers installing Tahoe Rear Strobes that need to remove the rear struts CANNOT clamp on the struts to hold open the liftgate. Use of a clamping device could damage the liftgate strut rod seals.

Repair/Recommendation:

WARNING: When a liftgate hold open device is being removed or installed, provide alternate support to avoid possibility of damage to the vehicle or personal injury.

CAUTION: Apply pressure only at the end of the liftgate assist rod that you are removing or attaching. Do NOT apply pressure to the middle of the rod because damage or bending will result.

NOT ACCEPTABLE EXAMPLE

ACCEPTABLE EXAMPLE

Disclaimer: GM Upfitter Integration Technical Bulletins are intended for use by professional technicians, NOT a "do-it-yourselfer". They are written to inform these technicians of conditions that may occur on some vehicles, or to provide information that could assist in the proper service and/or modification of a vehicle. These properly trained technicians have the equipment, tools, safety instructions, and know-how to do a job properly and safely. If a condition is described, DO NOT assume that the bulletin applies to your vehicle, or that your vehicle will have that condition. Contact GM Upfitter Integration for information on whether the information is applicable your vehicle.